

SUBJECT: Shouldered Stud Installation

PART/VEHICLE: G63929 (92- 07 Ford E-Series)

PROBLEM DESCRIPTION:

Installer unable to install the upper hardware on stud ended shocks designed with a “shoulder”. A shouldered stud is defined as a stud that has a non threaded zone that is larger in diameter than the threaded zone.

NOTE: The mounting kit includes two retainers with different size holes

Installing the retainer with the small hole first does not allow enough room to install the upper cushion, retainer and nut.



SOLUTION:

Installing the retainer with the large center hole first allows plenty of threaded area to install the shock.

