



FleetLine® GasSLX®

Interchange Intercambio Échange

FleetLine	GasSLX	FleetLine	GasSLX
83122	89406	85067	89451
83123	89405	85069	89455
83124	89407	85070	89459
83126	89430	85084	89460
83128	89436	85300	89419
83203	89436	85302	89420
83207	89407	85303	89422
83209	89414	85308	89422
83312	89409	85310	89423
83389	89436	85311	89424
83456	89447	85314	89425
85000	89436	85316	89426
85001	89410	85319	89428
85003	89411	85320	89429
85005	89430	85323	89436
85012	89413	85705	89447
85013	89414	85724	89443
85023	89415	85906	89407
85030	89440	85916	89430
85033	89427	85918	89449
85036	89405	85920	89503
85046	89434	85923	89458
85047	89435	85924	89457
85053	89442	85931	89458
85055	89439	85932	89453
85058	89431	85933	89454
85061	89450	85936	89456
85062	89408		
85066	89448		



IMPORTANT NOTE: Interchange must only be used for FLEETLINE to GasSLX upgrade. Interchange is NOT REVERSIBLE.

NOTA IMPORTANTE: El intercambio se debe utilizar solamente de FLEETLINE a GasSLX mejorado. El intercambio NO ES REVERSIBLE.

REMARQUE IMPORTANTE: L'échange ne peut se faire que pour le surclassement du FLEETLINE au GasSLX. L'échange N'EST PAS REVERSIBLE.