




FleetLine®  GasSLX®

Interchange

Intercambio
Échange

FleetLine	GasSLX	FleetLine	GasSLX
83123	89405	85058	89431
85036	89405	85046	89434
83122	89406	85047	89435
83124	89407	83128	89436
83207	89407	83203	89436
85906	89407	83389	89436
85062	89408	85000	89436
83312	89409	85323	89436
85001	89410	85055	89439
85003	89411	85030	89440
85012	89413	85053	89442
83209	89414	85724	89443
85013	89414	83456	89447
85023	89415	85705	89447
85300	89419	85066	89448
85302	89420	85918	89449
85303	89422	85061	89450
85308	89422	85067	89451
85310	89423	85932	89453
85311	89424	85933	89454
85314	89425	85069	89455
85316	89426	85936	89456
85033	89427	85924	89457
85319	89428	85923	89458
85320	89429	85931	89458
83126	89430	85070	89459
85005	89430	85084	89460
85916	89430	85920	89503



IMPORTANT NOTE: Interchange must only be used for FLEETLINE to GasSLX upgrade. Interchange is **NOT REVERSIBLE**.

NOTA IMPORTANTE: El intercambio se debe utilizar solamente de FLEETLINE a GasSLX mejorado. El intercambio **NO ES REVERSIBLE**.

REMARQUE IMPORTANTE: L'échange ne peut se faire que pour le surclassement du FLEETLINE au GasSLX. L'échange **N'EST PAS REVERSIBLE**.

Gabriel HD
THE ORIGINAL